

PCI-P16R16/PCI-P8R8

PnPDriver Installation Manual

[For Windows 95/98]

Warranty

All products manufactured by ICP DAS are warranted against defective materials for a period of one year from the date of delivery to the original purchaser.

Warning

ICP DAS assumes no liability for damage consequent to the use of this product. ICP DAS reserves the right to change this manual at any time without notice. The information furnished by ICP DAS is believed to be accurate and reliable. However, ICP DAS assumes no responsibility for its use, or for any infringements of patents or other rights of third parties resulting from its use.

Copyright

Copyright 1997-1999 by ICP DAS. All rights are reserved.

Trademark

The names used for identification only maybe registered trademarks of their respective companies.

License

The user can use and backup this software **on a single machine.**
The user may not reproduce, transfer or distribute this software, or any copy, in whole or in part.

After the user plug the PCI-P16R16/PCI-P8R8 on main-board and turn on the power of computer system. The user will see these windows as followings. Please follow these steps to finish this driver installation. Refer to Figure 1 to 15.




Figure 1. Click on the button “Next >” to install driver




Figure 2. Click on the button “Next >” to search device




Figure 3. Click on the button “Next>” to search drivers




Figure 4. Select the second item and click “Next >”




Figure 5. Select the item “Other devices” and click “Next>”




Figure 6. Click the button “Have Disk...”



Figure 7. Click the button “Browse” to select driver




Figure 8. Click “OK” after select the driver “P16R16.inf”.
This folder is corresponding on the CD-ROM drive.
(Note: PCI-P8R8 uses the driver P8R8.inf)




Figure 9. Click “OK”
(Note: PCI-P8R8 uses the driver P8R8.inf)




Figure 10. Click on the button “Next>”




Figure 11. Click “Next>”
(Note: PCI-P8R8 uses the driver P8R8.inf)




Figure 12. Click “Finish”




Figure 13. Double click the item “System” in the folder “Control Panel”




Figure 14. Select the device “PCI-P16R16” (or PCI-P8R8) and click button “Properties”




Figure 15. Please ensure that this device has no conflicts with other devices.